

ContainerPower Energy Solutions

Base Station Site Solution



Overview

How do I set up a base station?

Set up the base station using either the tripod or T-bar mounting method. You must use an external radio antenna kit for the internal 450 MHz or 900 MHz radio. To avoid interference between the 900 MHz radio and GPRS transmissions, do not mount the external radio antenna within 1 m (3.3 ft) of the GSM antenna.

How do I check if a base station is connected to IBSS?

Check the base station details to ensure that the base radio is indicating it is connected to IBSS through an SNM941 Connected Site Gateway. Your base station is now up and running. Log into to check the status. Equipment: Procedure: Insert the SIM card into the SNM940 modem, if required, and then reseal the unit.

What is a semi-permanent GNSS base station?

A semi-permanent or permanent base station helps to eliminate the types of error that can result from repeated daily setups, and ensures that you always use the GNSS antenna at the exact original location.

Base Station Site Solution

Contact Us

For catalog requests, pricing, or partnerships, please visit:
<https://www.websparafotografos.es>